

# SPETEC PUMP CLEANER

## REUSABLE, BIODEGRADABLE PUMP FLUSH

### DESCRIPTION

SPETEC PUMP CLEANER is a high performance pump flush that is friendly to the environment and does an excellent job flushing out injection pumps.

### USES

- Flushing injection resin out of pumping equipment.

### ADVANTAGES

- Optimal viscosity for flushing pumps.
- Prevents urethane from curing inside of the pumps.
- Low toxicity.
- Reusable.
- Biodegradable.

### APPLICATION

Note: the following are a few typical application descriptions. In case of other jobsite parameters, please contact our technical department.

#### PRELIMINARY ANALYSES

Flushing procedures vary based on type of pump, o-ring and seal material, and type of material being pumped. Confirm appropriate cleaning and flush methods with manufacturer of pump and manufacturer of material. For Alchemy-Spetec pumps, please see specific pump technical data sheet or contact Alchemy-Spetec for technical assistance.

#### PREPARATION OF THE SUBSTRATE

Most pumps are to be purged of material prior to flushing. Keep in mind that any construction chemicals mixed with flush will be compromised in performance and behavior.

#### PREPARATION OF THE PRODUCT

No special preparation is required for Spetec Pump Cleaner.

#### PREPARATION OF THE EQUIPMENT

Flushing procedures vary based on type of pump, o-ring and seal material, and type of material being pumped. Confirm appropriate cleaning and flush methods with manufacturer of pump and manufacturer of material. For Alchemy-Spetec pumps, please see specific pump technical data sheet or contact Alchemy-Spetec for technical assistance.

#### APPLICATION

- Initial Flush: Pour one to two gallons of Spetec Pump Cleaner into clean 5 gallon (18.9 liter) pail
- Purge resin material from pump with Spetec Pump Cleaner into waste pail until clean stream of solvent is flowing from output hose.
- The resin rich solvent from this phase will need to be disposed of properly.
- Recirculation: Direct the output hose back into the solvent pail and allow pump to re-circulate for 2 -3 minutes. Retain this used solvent for the initial flush sequence.

- Final Flush: Pour one to two gallons (3.79 to 7.57 liters) of fresh Spetec Pump Cleaner into a clean 5 gallon (18.9 liter) pail.
- Purge the previously used Spetec Pump Cleaner from the pump. When a clear stream of solvent flows from the output hose direct the flow back into the solvent pail and recirculate for 2 -3 minutes.
- Purge Spetec Pump Cleaner from pump with low viscosity motor oil for storage. Retain this used solvent for recirculation or final flush sequence.
- Reusing Spetec Pump Cleaner: Spetec Pump Cleaner can be used multiple times.
- Dispose of Spetec Pump Cleaner properly once the material is too stained to see through.

#### REQUIRED TOOLS

Pump, purge containers/vessels.

#### CLEANING AND MAINTENANCE

Flushing procedures vary based on type of pump, o-ring and seal material, and type of material being pumped. Confirm appropriate cleaning and flush methods with manufacturer of pump and manufacturer of material. For Alchemy-Spetec pumps, please see specific pump technical data sheet or contact Alchemy-Spetec for technical assistance.

#### COMPLIMENTARY PRODUCTS

Solvents, motor oil, flush pot.

#### ADVICE / FOCAL POINTS

Spetec Pump Cleaner and Spetec Pump Flush are not compatible with Viton or Buna-N

### TECHNICAL DATA

**Physical Properties:** Flashpoint > 175° F (79° C)

### ESTIMATING QUANTITIES

Approximately four gallons (15.1 liters) per side per use.

### PACKAGING

Spetec Pump Cleaner is supplied in 5 Gallon Pails (18.9 Liter Pails)

### STORAGE AND SHELF LIFE

Store in dry environment between 40° - 80° F (5° - 26° C). Protect from moisture.

### SAFETY PRECAUTIONS

Avoid contact with eyes and skin, always use personal protective equipment in compliance with local regulations. Read the relevant Safety Data Sheet before use. Safety Data Sheets are available on [www.alchemy-spetec.com](http://www.alchemy-spetec.com) When in doubt contact Alchemy-Spetec Technical Service.

FOR INDUSTRIAL USE ONLY. KEEP OUT OF REACH OF CHILDREN. NOT FOR INTERNAL CONSUMPTION. READ MATERIAL SAFETY DATASHEET PRIOR TO EVERY USE.